

RMU500-EKNM

EVB Kit User Guide

5G Module Series

Version: 1.0

Date: 2021-10-13

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local offices. For more information, please visit:

<http://www.quectel.com/support/sales.htm>.

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>.

Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties (“third-party materials”). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2021. All rights reserved.

Safety Information

The following safety precautions must be observed during all phases of operation, such as usage, service or repair of any cellular terminal or mobile incorporating the module. Manufacturers of the cellular terminal should notify users and operating personnel of the following safety information by incorporating these guidelines into all manuals of the product. Otherwise, Quectel assumes no liability for customers' failure to comply with these precautions.



Full attention must be paid to driving at all times in order to reduce the risk of an accident. Using a mobile while driving (even with a handsfree kit) causes distraction and can lead to an accident. Please comply with laws and regulations restricting the use of wireless devices while driving.



Switch off the cellular terminal or mobile before boarding an aircraft. The operation of wireless appliances in an aircraft is forbidden to prevent interference with communication systems. If there is an Airplane Mode, it should be enabled prior to boarding an aircraft. Please consult the airline staff for more restrictions on the use of wireless devices on an aircraft.



Wireless devices may cause interference on sensitive medical equipment, so please be aware of the restrictions on the use of wireless devices when in hospitals, clinics or other healthcare facilities.



Cellular terminals or mobiles operating over radio signal and cellular network cannot be guaranteed to connect in certain conditions, such as when the mobile bill is unpaid or the (U)SIM card is invalid. When emergency help is needed in such conditions, use emergency call if the device supports it. In order to make or receive a call, the cellular terminal or mobile must be switched on in a service area with adequate cellular signal strength. In an emergency, the device with emergency call function cannot be used as the only contact method considering network connection cannot be guaranteed under all circumstances.



The cellular terminal or mobile contains a transceiver. When it is ON, it receives and transmits radio frequency signals. RF interference can occur if it is used close to TV sets, radios, computers or other electric equipment.



In locations with explosive or potentially explosive atmospheres, obey all posted signs and turn off wireless devices such as mobile phone or other cellular terminals. Areas with explosive or potentially explosive atmospheres include fueling areas, below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air contains chemicals or particles such as grain, dust or metal powders.

About the Document

Revision History

| Version | Date | Author | Description |
|---------|------------|-----------|--------------------------|
| - | 2021-09-27 | Albert XU | Creation of the document |
| 1.0 | 2021-10-13 | Albert XU | First official released |

Contents

| | |
|---|-----------|
| Safety Information | 3 |
| About the Document | 4 |
| Contents | 5 |
| Table Index | 6 |
| Figure Index | 7 |
| 1 Introduction | 8 |
| 1.1. Applicable Modules..... | 8 |
| 2 General Overview | 9 |
| 2.1. Key Features..... | 9 |
| 2.2. Component Placement of the EVB..... | 10 |
| 2.3. Top and bottom View of the EVB..... | 11 |
| 2.4. EVB Kit Accessories..... | 12 |
| 3 Interface Application | 13 |
| 3.1. Power Supply (J101/J301)..... | 13 |
| 3.2. M.2 Interface (J201)..... | 14 |
| 3.3. USB Interface (J301)..... | 15 |
| 3.4. (U)SIM Interface (J401)..... | 16 |
| 3.5. Status Indicator (D104/D107)..... | 17 |
| 3.6. RF Cables and Antennas..... | 18 |
| 3.6.1. Antenna Design..... | 18 |
| 3.6.2. Antenna Efficiency..... | 19 |
| 3.6.3. Antenna Specification..... | 20 |
| 4 EVB Operation Procedures | 22 |
| 4.1. Component Assembling Steps..... | 22 |
| 4.2. Turn On the Module..... | 26 |
| 4.3. Communication Via USB Interface..... | 26 |
| 4.4. Firmware Upgrade..... | 27 |
| 4.5. Turn Off the Module..... | 28 |
| 5 Appendix References | 29 |

Table Index

| | |
|---|----|
| Table 1: Applicable Modules | 8 |
| Table 2: Key Features | 9 |
| Table 3: Interfaces of the EVB | 10 |
| Table 4: List of Accessories | 12 |
| Table 5: Pin Definition of J401 | 17 |
| Table 6: Description of Status Indicator LEDs | 18 |
| Table 7: Antenna Specification | 20 |
| Table 8: Related Documents..... | 29 |
| Table 9: Terms and Abbreviations | 29 |

Figure Index

| | |
|--|----|
| Figure 1: Component Placement of the EVB (Top View) | 10 |
| Figure 2: EVB Top View | 11 |
| Figure 3: EVB Bottom View | 11 |
| Figure 4: EVB Power Supply Interfaces..... | 13 |
| Figure 5: M.2 Connector of the EVB | 14 |
| Figure 6: USB Connector | 15 |
| Figure 7: Connection Between PC and EVB | 15 |
| Figure 8: Simplified Connection Schematic for (U)SIM Card Connector J401 | 16 |
| Figure 9: Pin Assignment of (U)SIM Card Connector J401 | 16 |
| Figure 10: Status Indicators | 17 |
| Figure 11: Reference Design for Antennas | 18 |
| Figure 12: Antenna Efficiency at 700–960 MHz and 1.7–6 GHz..... | 19 |
| Figure 13: Antenna Efficiency at 1.7–6 GHz..... | 19 |
| Figure 14: RM500Q-CN/RM500Q-GL RF cable Sequence..... | 20 |
| Figure 15: RM500Q-AE/RM502Q-AE RF Cable Sequence | 21 |
| Figure 16: Assembling (Step One)..... | 22 |
| Figure 17: Assembling (Step Two)..... | 23 |
| Figure 18: Assembling (Step Three) | 23 |
| Figure 19: RM500Q-CN/RM500Q-GL RF Cable Assembly | 24 |
| Figure 20: RM500Q-AE/RM502Q-AE RF Cable Assembly..... | 24 |
| Figure 21: Assembling (Step Four) | 25 |
| Figure 22 Assembling (Step Five)..... | 25 |
| Figure 23: Assembled EVB Kit..... | 26 |
| Figure 24: USB Ports | 27 |
| Figure 25: COM Port Setting Field on QCOM (USB AT Port Connection)..... | 27 |
| Figure 26: Configurations for Firmware Upgrade | 28 |

1 Introduction

This document introduces the EVB kit, RMU500-EKNM, for Quectel 5G M.2 modules, which is an assistant tool kit for engineers to develop and test the modules.

1.1. Applicable Modules

Table 1: Applicable Modules

| Module Series | Models |
|---------------|-----------|
| 5G | RM500Q-CN |
| | RM500Q-GL |
| | RM500Q-AE |
| | RM502Q-AE |

2 General Overview

Quectel provides the RMU500-EKNM EVB kit for engineers to develop applications based on 5G M.2 modules and to test basic functionalities of the applicable modules.

2.1. Key Features

Table 2: Key Features

| Features | Description |
|--------------------------|---|
| Power Supply | DC power supply: +5 V/ 2.5 A for the EVB |
| M.2 Interface | Interface to mount applicable 5G M.2 modules |
| (U)SIM Interface | Support 1.8/2.95 V (U)SIM card |
| USB Interface | <ul style="list-style-type: none"> ● USB Type-C Interface ● USB 2.0 & USB 3.1 |
| Status Indication | 2 LEDs available for signal indication |
| Physical Characteristics | Size: 100 mm × 60 mm |

2.2. Component Placement of the EVB




Figure 1: Component Placement of the EVB (Top View)

Table 3: Interfaces of the EVB

| Interfaces | Reference Designator | Description |
|------------------|----------------------|--|
| Power Supply | J101 (Power Jack) | The power jack on the EVB Typical supply voltage: +5 V/ 2.5 A |
| M.2 Interface | J201 | The M.2 connector for the module |
| USB Interface | J301 | USB Type-C interface used for: <ul style="list-style-type: none"> ● data transmission ● power supply (typical supply voltage: +5 V/ 2 A) |
| (U)SIM Interface | J401 | (U)SIM card connector |
| Indication LEDs | D104 (POWER_LED) | Power indicator, indicating whether the module's power supply is ready |
| | D107 (WWAN_LED) | RF status indicator for the module |

2.3. Top and bottom View of the EVB

The following figure shows the top view of the EVB.




Figure 2: EVB Top View

The following figure shows the bottom view of the EVB.




Figure 3: EVB Bottom View

2.4. EVB Kit Accessories

Table 4: List of Accessories

| Item | Description | Quantity (pcs) |
|-------------------|---|----------------|
| Cable | Type-C to dual Type-A cable | 1 |
| | RF cables | 4 |
| Antenna | Antennas with brackets | 4 |
| Soft silicone pad | Thermal conductive pad | 1 |
| Heatsink | Black anodized AL6063 | 1 |
| USB flash drive | Including the related documents, tools, and drivers for the module and RMU500-EKNM. | 1 |
| Screw | Used to clamp the module, antennas and heatsink on the EVB | 19 |

NOTE

NONE of the applicable 5G M.2 modules are included as accessories of the RMU500-EKNM EVB kit. RF cables, heatsink, soft silicone pad, and screws are included as accessories.

3 Interface Application

This chapter describes the following hardware interfaces of RMU500-EKNM:

- Power supply (J101/J301)
- M.2 interface (J201)
- USB interface (J301)
- (U)SIM interface (J401)
- RF cables and antennas

It also provides information about the status indicator LEDs (D104/D107) to help you use the EVB.

3.1. Power Supply (J101/J301)

The EVB is powered by an external power adapter through the power jack (J101) on the EVB. It can also be powered by the USB interface (J301, referring to **Chapter 3.3**).

The following figure shows the power supply interfaces of the EVB.




Figure 4: EVB Power Supply Interfaces

3.2. M.2 Interface (J201)

The M.2 connector is designed to accommodate the module. The following figure shows the M.2 connector on the EVB.




Figure 5: M.2 Connector of the EVB

3.3. USB Interface (J301)

The EVB provides a Type-C USB connector (J301) for the connection with a host. Type-C USB can be used for data transmission. Also, it can be used as power supply interface to power on the EVB.




Figure 6: USB Connector




Figure 7: Connection Between PC and EVB

One end of Type-A is connected to the computer, and, when necessary (e.g., when power supply from the Type-A connected to the PC is inadequate), the other end is connected to the auxiliary power supply.

3.4. (U)SIM Interface (J401)

The EVB has an 8-pin push-push type (U)SIM card (1.8/2.95 V) connector (J401). The following figure shows a simplified connection schematic for the (U)SIM card connector.




Figure 8: Simplified Connection Schematic for (U)SIM Card Connector J401

The figure and table below illustrate the pin assignment and pin definition of (U)SIM card connector.




Figure 9: Pin Assignment of (U)SIM Card Connector J401

Table 5: Pin Definition of J401

| Pin No. | Pin Name | I/O | Function |
|---------|-----------|-----|--------------------------|
| C1 | USIM_VDD | PO | (U)SIM card power supply |
| C2 | USIM_RST | DO | (U)SIM card reset |
| C3 | USIM_CLK | DO | (U)SIM card clock |
| C4 | RESERVED | - | Not connected |
| C5 | GND | - | Ground |
| C6 | VPP | - | Not connected |
| C7 | USIM_DATA | DIO | (U)SIM card data |
| C8 | RESERVED | - | Not connected |
| CD | USIM_DET | DI | (U)SIM card detection |

3.5. Status Indicator (D104/D107)

The EVB provides two status indicator LEDs (D104 and D107). The following figure shows the positions of these indicators.




Figure 10: Status Indicators

Table 6: Description of Status Indicator LEDs

| Reference Designator | Description |
|----------------------|---|
| D104 (POWER_LED) | Power indicator, indicating whether the module's power supply is ready. Light on: power on Light off: power off |
| D107 (WWAN_LED) | RF status indicator for the module. Light on: RF function is enabled Light off: RF function is disabled |

3.6. RF Cables and Antennas

3.6.1. Antenna Design

The following figure is a typical reference design for antennas of the EVB kit.




Figure 11: Reference Design for Antennas

The matching circuit is composed of C1, C2 and R1 for antenna impedance modification. The value of R1 is 0 Ω, while C1 and C2 are not mounted by default.

3.6.2. Antenna Efficiency




Figure 12: Antenna Efficiency at 700–960 MHz and 1.7–6 GHz




Figure 13: Antenna Efficiency at 1.7–6 GHz

NOTE

All measurements are done for the antennas of the RMU500-EKNM EVB kit with Agilent E5071C ENA network analyzer and OTA chamber.

3.6.3. Antenna Specification

The specification of antennas is provided in the following table.

Table 7: Antenna Specification

| Antenna | Specification |
|---------|---|
| Ant 0 | Frequency Range: 0.7–6 GHz Input Impedance: 50 Ω |
| Ant 1 | Frequency Range: 1.7–6 GHz Input Impedance: 50 Ω |
| Ant 2 | Frequency Range: 1.7–6 GHz Input Impedance: 50 Ω |
| Ant 3 | Frequency Range: 0.7–6 GHz Input Impedance: 50 Ω |

The cable assembly varies when different modules are used with this EVB kit. The installations for RM500Q-CN and RM500Q-GL are the same, so does that for RM500Q-AE and RM502Q-AE). The following figures illustrate these cable connections.




Figure 14: RM500Q-CN/RM500Q-GL RF cable Sequence




Figure 15: RM500Q-AE/RM502Q-AE RF Cable Sequence

NOTE

1. Ant 0–3 have been assembled on the EVB to prevent damage during transportation.
2. The RM500Q-CN module, which supports GNSS L1 + L5, cannot support L5 in this case because the frequency range of Ant 1 is 1.7–6 GHz.

4 EVB Operation Procedures

This chapter introduces how to assemble and use the RMU500-EKNM EVB kit to test and evaluate the module.

4.1. Component Assembling Steps

Please follow these steps to assemble the product.

Step 1: Remove the antennas one by one, and keep the antennas and screws.




Figure 16: Assembling (Step One)

Step 2: Attach the thermal conductive pad, insert the module, and lock the screw.




Figure 17: Assembling (Step Two)

Step 3: Insert four RF cables. There are two RF cable assembling methods when the EVB kit is used with different modules.




Figure 18: Assembling (Step Three)




Figure 19: RM500Q-CN/RM500Q-GL RF Cable Assembly




Figure 20: RM500Q-AE/RM502Q-AE RF Cable Assembly

Step 4: Place the heatsink on the module and tighten the screws.




Figure 21: Assembling (Step Four)

Step 5: Assemble the antenna in turn and tighten the screws.




Figure 22 Assembling (Step Five)

Then, the assembly is finished. The assembled EVB kit is shown below.




Figure 23: Assembled EVB Kit

4.2. Turn On the Module

1. Finish the assembling steps above.
2. Insert a (U)SIM card into the (U)SIM card connector on the EVB.
3. Insert the USB cable (Type-C to dual Type-A). Connect the type-C end to the EVB, one Type-A end to the computer, and the other Type-A end to an auxiliary power supply. The module will be turned on automatically when the EVB is powered through the USB interface (J301) or the power jack (J101).

4.3. Communication Via USB Interface

1. Power on the module according to the procedure in **Chapter 4.1**.
2. When the EVB is connected to a PC with the USB Type-C cable through the USB interface, run the USB driver disk on the PC to install the USB driver. For details about USB driver installation, see **document [1]**. The USB port numbers can be viewed in Device Manager of the PC when the USB driver is installed, as shown below.



Figure 24: USB Ports

3. Install and then use QCOM provided by Quectel to realize the communication between the module and the PC.

The following figure shows the COM Port Setting of QCOM: select correct “**COM Port**” (USB AT Port which is shown in the figure above) and set correct “**Baudrate**” (e.g. 115200 bps). For more details about QCOM usage and configuration, see *document [2]*.




Figure 25: COM Port Setting Field on QCOM (USB AT Port Connection)

4.4. Firmware Upgrade

Firmware of the module is upgraded via USB port by default, please follow the procedures below to upgrade the firmware.

1. Install and open the firmware upgrade tool, QFlash, on the PC and then turn on the module according to the procedures in *Chapter 4.2*.
2. Click the “**COM Port**” dropdown list and select the Port No. corresponding to “Quectel USB DM Port” in the Device Manager.
3. Click the “**Load FW Files**” button and choose the firmware package.
4. Click the “**Start**” button to upgrade the firmware.




Figure 26: Configurations for Firmware Upgrade

For more details about QFlash usage and configuration, see *document [3]*.

4.5. Turn Off the Module

There are two methods to turn off the module.

- Hardware method: the module will be turned off after the power supply is disconnected.
- Software method: the module can be turned off with **AT+QPOWD** command, which is a preferred and safer method. The module will log off from the network and save data before shutdown.

5 Appendix References

Table 8: Related Documents

| Document Name |
|--|
| [1] Quectel_LTE&5G_Windows_USB_Driver_Installation_Guide |
| [2] Quectel_QCOM_User_Guide |
| [3] Quectel_QFlash_User_Guide |
| [4] Quectel_RG50xQ&RM5xxQ_Series_AT_Commands_Manual |

Table 9: Terms and Abbreviations

| Abbreviation | Description |
|--------------|-----------------------|
| COM | Communication Port |
| DC | Direct Current |
| DI | Digital Input |
| DO | Digital Output |
| EVB | Evaluation Board |
| GND | Ground |
| I/O | Input/Output |
| LED | Light Emitting Diode |
| NC | Not Connected |
| PC | Personal Computer |
| PCB | Printed Circuit Board |

| | |
|--------|---|
| PO | Power Output |
| RF | Radio Frequency |
| SD | Secure Digital |
| SIM | Subscriber Identity Module |
| UART | Universal Asynchronous Receiver & Transmitter |
| USB | Universal Serial Bus |
| (U)SIM | (Universal) Subscriber Identity Module |
